

Item number: INBACTOS001R000

The Toshiba-BACnet interface allows full bidirectional communication between Toshiba VRF and Digital Air Conditioner units and BACnet/IP or MS/TP networks. It enables BACnet communication via polling or subscription requests (COV), making the indoor unit available through independent BACnet objects. A wired remote controller can also be connected.



Toshiba to BACnet/IP & MS/TP - 1 indoor unit

Features and benefits

- Support for BACnet/IP and BACnet MS/TP

 BACnet/IP (via Ethernet) or BACnet MS/TP (via EIA-485) connection options are supported.
- IP settings available via a web interface
 A configuration tool is available via a web interface with IP settings and more information.
- Occupancy function to allow energy savings Occupancy function that helps reduce costs, as HVAC systems are one of the main energy consumers.
- AC unit control by remote and BACnet/IP or MS/TP The AC unit can simultaneously be controlled via BACnet/IP or MS/TP and its own remote controller.

- Configuration from onboard DIP switches

 The interface configuration is carried out directly through its onboard DIP switches.
- AC unit data served as fixed BACnet Objects

 Air conditioning unit properties and functionalities are abstracted into fixed BACnet Objects.
- Total unit control and monitoring from BACnet

 Through internal variables, running hours counter (for maintenance purposes), and error indication.
- No external power required

 The interface is powered directly from the AC unit, so no external power supply is required.





Identification and Status	
Product ID	INBACTOS001R000
Country of Origin	Spain
HS Code	8517620000
Export Control Classification Number (ECCN)	EAR99
General	
Net Width (mm)	53
Net Height (mm)	58
Net Depth (mm)	93
Net Weight (g)	120
Operating Temperature °C Min	0
Operating Temperature °C Max	60
Input Voltage (V)	From the AC unit.
Power Connector	Other
Capacity	1 indoor unit.
Installation Conditions	This gateway is designed to be mounted inside an enclosure. If the unit is mounted outside an enclosure, precautions should always be taken to prevent electrostatic discharge to the unit. When working inside an enclosure (e.g., making adjustments, setting switches, etc.), typical anti-static precautions should always be followed before touching the unit.
Content of Delivery	Intesis Gateway, Installation Manual.
Mounting	DIN rail mount (bracket included), Wall mount
Housing Materials	Plastic
Warranty (years)	3 years
Packaging Material	Cardboard






Certifications and Standards	
ETIM Classification	EC001604
WEEE Category	IT and telecommunications equipment





Use Case



*BACnet IP or BACnet MSTP communication selectable from switch configuration

Integration example.

